

Cough & Sneeze Detection Using Yolov3

Introduction:

Activity recognition aims to recognize the actions and goals of one or more persons from a series of observations on the persons' actions and the environmental conditions using artificial intelligence. Here we have used Activity Detection for Cough and Sneeze detection.

Use Cases:

- Health Sector.
- In Shopping Areas for prevention during pandemic.
- Hospitals.
- Can be used in Schools or any other area.

Dataset Collection:

For dataset we've used videos from biisc dataset of Activity Detection (BII Sneeze-Cough Human Action Video Dataset). Because we focus only on two actions so we only extract the cough and sneeze videos from dataset and extract frames out of them.

Dataset: <https://web.bii.a-star.edu.sg/~chengli/FluRecognition.htm>

Code:

```
#For sneeze and cough both

import os

import cv2

pathOut = r"/Users/Aveen Faheem/Desktop/sneezeimg/"

count = 0

counter = 1

listing = os.listdir(r'/Users/Aveen Faheem/Desktop/sneeze')

for vid in listing:

    vid = r"/Users/Aveen Faheem/Desktop/sneeze/" + vid

    cap = cv2.VideoCapture(vid)
```

```

count = 0

counter += 1

success = True

while success:

    success,image = cap.read()

    print('Read a new frame:',success)

    if count%30 == 0 :

        cv2.imwrite(pathOut + 'video%d'%counter + 'sneeze%d.jpg'%count ,image)

        count+=1

```

For Re-naming the files

```

import os

os.getcwd()

collection = "/Users/Aveen Faheem/Desktop/sneezeimg"

for i, filename in enumerate(os.listdir(collection)):

    os.rename("/Users/Aveen Faheem/Desktop/sneezeimg/" + filename, "/Users/Aveen
Faheem/Desktop/sneezeimg/" + "sneeze" + str(i) + ".jpg")

```

Annotations:

For annotations of these images I've used LabelImg. You can use it by following these steps.

1. Pip install labelImg
2. Go to command prompt and write labelimg
3. It will pop-up and you can annotate your images.
4. Map the desired area, label it and save in .txt format.
5. Make sure you are keeping the classes values right.

Methodology:

Custom Activity Detection on yolov3 of Cough and Sneeze:

For training yolov3 model on collab, I've followed these steps.

1. Download Darknet
<https://github.com/pjreddie/darknet>

Download darknet and make changes in Make file
GPU = 1
CUDNN=1
OPENCV=1

Replace new make file with old one in colab.

2. Download Pre-trained weights for yolov3

<https://pjreddie.com/media/files/darknet53.conv.74>

Keep these weights in darknet folder on colab.

3. Changes in cfg file

In directory **darknet\cfg**, creating a copy of “**yolov3.cfg**” in the same folder and rename it.

Make these changes according to your number of classes.

Line 8 & 9:

width = 416, height = 416

Line 20

max_batches = 6000

Line 22

steps = 5400

#Line 603, 689, 776:

filters = 18

#Line 610, 696, 783:

classes = 1

Formula for filters = (filters = (classes + 5)*3)

filters=(2+5)*3 = 21 classes = 2.

After making changes add this cfg file in cfg folder.

4. Detector.c file

From directory **darknet\examples** folder, open file “**detector.c**” . At line 138, modify this line as below:

```
if(i%1000==0 || (i < 1000 && i%100 == 0)){
```

5. Split Train and Test data

Code:

```

import glob, os
## Current directory
current_dir = '/content/drive/My Drive/backup/' # Path to the current directory
#print(current_dir)

# Percentage of images to be used for the test set
percentage_test = 10;

# Create and/or truncate train.txt and test.txt
file_train = open('train.txt', 'w')
file_test = open('test.txt', 'w')

# Populate train.txt and test.txt
counter = 1
index_test = round(100 / percentage_test)

for pathAndFilename in glob.iglob(os.path.join(current_dir, "*.jpg")):
    title, ext = os.path.splitext(os.path.basename(pathAndFilename))
    if counter == index_test:
        counter = 1
        file_test.write(current_dir + title + '.jpg' + "\n")
    else:
        file_train.write(current_dir + title + '.jpg' + "\n")
        counter = counter + 1

```

After dividing train and test data, change their paths according to colab path to access data from drive. Keep all these files along with data on drive as well.

6. Data and names file

Change names file according to given annotations 0 or 1 to which activity.

0 cough

1 sneeze so make names file as

Cough

Sneeze

For data file add these things

classes= 1 #number of objects, in our case is 1

train = data/train.txt

test = data/test.txt

names = data/yolo.names

backup = backup

7. Setting Colab

- After downloading darknet to colab.
- Replace makefile
- Add cfg file in cfg folder
- Add(train.txt, test.txt, names file, data file) in data folder
- Change detector.c in examples folder
- Add darknet53.conv74 to darknet folder.


For more guidance follow these links

<https://medium.com/@quangnhatnguyenle/how-to-train-yolov3-on-google-colab-to-detect-custom-objects-e-g-gun-detection-d3a1ee43eda1>

<https://colab.research.google.com/drive/13-9pAz9nxUYm-0LINV9tVtS57g8mHAOb#scrollTo=fBQgzSpY7Vkh>

<https://github.com/pjreddie/darknet/issues/174>

Training:



cough.ipynb - Colaboratory x backup - Google Drive x +

colab.research.google.com/drive/1t0JQca2AVQD7bSc-iCezcDCO5zs4iWj#scrollTo=Xj4DirDteowy

Apps Google YouTube Maps Google Docs Forces Test Movies & TV Series... Siamese_Networks... N-Shot Learning: Le... State Bank of Pakist... msc-thesis.p

cough.ipynb ☆

File Edit View Insert Runtime Tools Help All changes saved

Files

Upload Refresh Mount Drive

.. yoloov31.cfg
darknet
backup
cfg
data
examples
include
obj
python
results
scripts
src
LICENSE
LICENSE.fuck
LICENSE.gen
LICENSE.gpl
LICENSE.meta
LICENSE.mit

+ Code + Text

```
[1] from google.colab import drive
drive.mount('/content/drive')
```

Go to this URL in a browser: https://accounts.google.com/o/oauth2/auth?client_id=947318989803-6bn6qk8qdgf4n

Enter your authorization code:
.....
Mounted at /content/drive

```
[2] !git clone https://github.com/pjreddie/darknet
```

Cloning into 'darknet'...
remote: Enumerating objects: 5904, done.
remote: Total 5904 (delta 0), reused 0 (delta 0), pack-reused 5904
Receiving objects: 100% (5904/5904), 6.32 MiB | 8.79 MiB/s, done.
Resolving deltas: 100% (3922/3922), done.

```
[3] !nvcc --version
```

nvcc: NVIDIA (R) Cuda compiler driver
Copyright (c) 2005-2019 NVIDIA Corporation
Built on Sun Jul 28 19:07:16 PDT 2019

cough.ipynb - Colaboratory x backup - Google Drive x +

colab.research.google.com/drive/1t0JQca2AVQD7bSc-iCezcDCO5zs4iWj#scrollTo=Xj4DirDteowy

Apps Google YouTube Maps Google Docs Forces Test Movies & TV Series... Siamese_Networks... N-Shot Learning: Le... State Bank of Pakist... msc-thesis.p

cough.ipynb ☆

File Edit View Insert Runtime Tools Help All changes saved

Files

Upload Refresh Mount Drive

.. Datanev
darknet
drive
sample_data

+ Code + Text

55 res 52 26 x 26 x 512 -> 26 x 26 x 512

```
[ ] #to resume the training
!./darknet detector train data/yolo.data cfg/yolov31.cfg backup/yolov31_800.weights
```

yolov31

| layer | filters | size | input | output |
|---------|---------|-----------|-----------------|------------------------------|
| 0 conv | 32 | 3 x 3 / 1 | 416 x 416 x 3 | 416 x 416 x 32 0.299 BFLOPs |
| 1 conv | 64 | 3 x 3 / 2 | 416 x 416 x 32 | 208 x 208 x 64 1.595 BFLOPs |
| 2 conv | 32 | 1 x 1 / 1 | 208 x 208 x 64 | 208 x 208 x 32 0.177 BFLOPs |
| 3 conv | 64 | 3 x 3 / 1 | 208 x 208 x 32 | 208 x 208 x 64 1.595 BFLOPs |
| 4 res | 1 | | 208 x 208 x 64 | 208 x 208 x 64 |
| 5 conv | 128 | 3 x 3 / 2 | 208 x 208 x 64 | 104 x 104 x 128 1.595 BFLOPs |
| 6 conv | 64 | 1 x 1 / 1 | 104 x 104 x 128 | 104 x 104 x 64 0.177 BFLOPs |
| 7 conv | 128 | 3 x 3 / 1 | 104 x 104 x 64 | 104 x 104 x 128 1.595 BFLOPs |
| 8 res | 5 | | 104 x 104 x 128 | 104 x 104 x 128 |
| 9 conv | 64 | 1 x 1 / 1 | 104 x 104 x 128 | 104 x 104 x 64 0.177 BFLOPs |
| 10 conv | 128 | 3 x 3 / 1 | 104 x 104 x 64 | 104 x 104 x 128 1.595 BFLOPs |
| 11 res | 8 | | 104 x 104 x 128 | 104 x 104 x 128 |
| 12 conv | 256 | 3 x 3 / 2 | 104 x 104 x 128 | 52 x 52 x 256 1.595 BFLOPs |
| 13 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 0.177 BFLOPs |
| 14 conv | 256 | 3 x 3 / 1 | 52 x 52 x 128 | 52 x 52 x 256 1.595 BFLOPs |
| 15 res | 12 | | 52 x 52 x 256 | 52 x 52 x 256 |
| 16 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 0.177 BFLOPs |
| 17 conv | 256 | 3 x 3 / 1 | 52 x 52 x 128 | 52 x 52 x 256 1.595 BFLOPs |
| 18 res | 15 | | 52 x 52 x 256 | 52 x 52 x 256 |
| 19 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 0.177 BFLOPs |

cough.ipynb - Colaboratory backup - Google Drive

colab.research.google.com/drive/1t0JQca2AVQD7bSc-iCezcDCO5zs4iWj#scrollTo=Xj4DirDteowy

Apps Google YouTube Maps Google Docs Forces Test Movies & TV Series... Siamese_Networks... N-Shot Learning: Le... State Bank of Pakist... msc-thesis.p

cough.ipynb

File Edit View Insert Runtime Tools Help All changes saved

Files

Upload Refresh Mount Drive

- ..
- darknet
 - backup
 - cfg
 - data
 - examples
 - include
 - obj
 - python
 - results
 - scripts
 - src
 - LICENSE
 - LICENSE.fuck
 - LICENSE.gen
 - LICENSE.gpl
 - LICENSE.meta
 - LICENSE.mit

+ Code + Text

55 res 52 26 x 26 x 512 -> 26 x 26 x 512

```
[ ] #To resume the training
!./darknet detector train data/yolo.data cfg/yolov31.cfg backup/yolov31_800.weights
```

yolov31

| layer | filters | size | input | output |
|---------|---------|-----------|-----------------|-----------------|
| 0 conv | 32 | 3 x 3 / 1 | 416 x 416 x 3 | 416 x 416 x 32 |
| 1 conv | 64 | 3 x 3 / 2 | 416 x 416 x 32 | 208 x 208 x 64 |
| 2 conv | 32 | 1 x 1 / 1 | 208 x 208 x 64 | 208 x 208 x 32 |
| 3 conv | 64 | 3 x 3 / 1 | 208 x 208 x 32 | 208 x 208 x 64 |
| 4 res | 1 | | 208 x 208 x 64 | 208 x 208 x 64 |
| 5 conv | 128 | 3 x 3 / 2 | 208 x 208 x 64 | 104 x 104 x 128 |
| 6 conv | 64 | 1 x 1 / 1 | 104 x 104 x 128 | 104 x 104 x 64 |
| 7 conv | 128 | 3 x 3 / 1 | 104 x 104 x 64 | 104 x 104 x 128 |
| 8 res | 5 | | 104 x 104 x 128 | 104 x 104 x 128 |
| 9 conv | 64 | 1 x 1 / 1 | 104 x 104 x 128 | 104 x 104 x 64 |
| 10 conv | 128 | 3 x 3 / 1 | 104 x 104 x 64 | 104 x 104 x 128 |
| 11 res | 8 | | 104 x 104 x 128 | 104 x 104 x 128 |
| 12 conv | 256 | 3 x 3 / 2 | 104 x 104 x 128 | 52 x 52 x 256 |
| 13 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 |
| 14 conv | 256 | 3 x 3 / 1 | 52 x 52 x 128 | 52 x 52 x 256 |
| 15 res | 12 | | 52 x 52 x 256 | 52 x 52 x 256 |
| 16 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 |
| 17 conv | 256 | 3 x 3 / 1 | 52 x 52 x 128 | 52 x 52 x 256 |
| 18 res | 15 | | 52 x 52 x 256 | 52 x 52 x 256 |
| 19 conv | 128 | 1 x 1 / 1 | 52 x 52 x 256 | 52 x 52 x 128 |

Testing:

cough.ipynb x Real-time cu x M How to train x Colab_tutor x Machine_lee x backup - Go x Desktop/An x cough x (3) bts at the x Co

colab.research.google.com/drive/1t0JQca2AVQD7bSc-iCezdCO5szs4iWj#scrollTo=bfCcey39-qMn

Apps Google YouTube Maps Google Docs Forces Test Movies & TV Seires... Siamese_Networks... N-Shot Learning: Le... State Bank of Pakist... msc-thesis.p

cough.ipynb ☆

File Edit View Insert Runtime Tools Help All changes saved


Files

Connecting to a runtime to enable file browsing.

+ Code + Text

```
from google.colab import files
files.download(path)
```

imshow('predictions.jpg')



cough.ipynb x Real-time cu x M How to train x Colab_tutor x Machine_lee x backup - Go x Desktop/An x cough x (3) bts at the x Co

colab.research.google.com/drive/1t0JQca2AVQD7bSc-iCezdCO5szs4iWj#scrollTo=bfCcey39-qMn

Apps Google YouTube Maps Google Docs Forces Test Movies & TV Seires... Siamese_Networks... N-Shot Learning: Le... State Bank of Pakist... msc-thesis.p

cough.ipynb ☆

File Edit View Insert Runtime Tools Help All changes saved

Files


Upload Refresh Mount Drive



.. sample_data

+ Code + Text

```
def download(path):
    from google.colab import files
    files.download(path)
```

imshow('predictions.jpg')





Results:

On 3000 weights results are right and they are detecting the right part of images. In videos; on dataset videos it is giving right results but to new videos it is that much accurate still testing more to see results.